









Synchronous Belt Replacement Signs

Names of Belt Components



Examples of Belt Replacement Signs

Examples	Condition
<p>1. When belt tooth reinforcement fabric is worn and rubber/core wire are exposed</p> <p>When tooth surface/grooves are worn and rubber/core wire are exposed</p>	
<p>2. When the backing rubber shows cracks due to hardening</p>	
<p>3. When cracks reaching the rubber are seen at tooth base</p>	
<p>4. Belt side faces are damaged due to wear</p>	
<p>5. When missing tooth can be seen</p>	
<p>6. When excessive wear can be seen on belt back side</p>	
<p>7. When belt or core wire are broken</p>	

⚠ These are belt replacement timing guides. Early or periodical replacements are recommended even the signs shown above are not yet visible.